



## New World Industries

### **Wiring Installation Diagram for RF-5000**

Yellow wire is activated by button #1  
White wire is activated by button #2  
Green wire is activated by button #3  
Blue wire is activated by button #4  
Brown wire is activated by button #5  
Orange wire is activated by button #6  
Purple wire is activated by button #7  
Pink wire is activated by button #8  
Gray wire to pump coil if double pole is added  
Red wire is DC power supply  
Black wire is DC ground

#### **Intended usage:**

NWI has no control over the end usage of the RF-500 series wireless units. Because of this, NWI recommends that these units are intended for **OFF-ROAD** use only. NWI offers no written or expressed liability as to how this unit is used

Copyright, New World Industries Inc., 2006